

NOTE: Your gloves, the anesthesia induction chamber, animal resting surface, and anesthetic manifold must be sanitized, and allowed time to effectively decontaminate, Allow your decontaminated gloves to dry before handling mice prior to anesthetic induction.

SC195.3
Effective 4/23

3.5 x 5